

How to place an Omniliner 90° curved corner LDT file in Relux / Dialux

For : Corner R420, Corner R840 and Corner R1675

Place the 2 straight parts at 90° with a distance = R (see right drawing)

The curved corner is simulated by placing 2 x the curved LDT file (at 70° and at 20°)

