

How to place an Omniliner 45° curved corner LDT file in Relux / Dialux

For : Corner R840, Corner R1647 and Corner R2925

The curved corner is simulated by placing the curved LDT file at 67.5° on the first straight part
Place the 2nd straight part at 45° on the part that simulates the curved corner (see drawing)

