


PLATE 11

229 02 11



 [Voir sur le site Web](#)



Informations générales	
EMPLACEMENT	exterieur
POIDS (KG)	11.5

Utilisation à quel endroit ?

431 400 221 11	POLESANO 4M - 1 BASE
431 400 221 21	POLESANO 4M - 2 BASE
431 400 221 31	POLESANO 4M - 3 BASE
431 400 221 41	POLESANO 4M - 4 BASE
431 400 221 211	POLESANO 4M - 21L BASE
431 400 221 221	POLESANO 4M - 22L BASE
431 600 321 11	POLESANO 6M - 1 BASE
431 600 321 21	POLESANO 6M - 2 BASE
431 600 321 31	POLESANO 6M - 3 BASE
431 600 321 41	POLESANO 6M - 4 BASE
431 600 321 211	POLESANO 6M - 21L BASE
431 600 321 221	POLESANO 6M - 22L BASE
26071 0010	POLE 80 4M - 4 BASE
26071 0020	POLE 80 6M - 4 BASE
26071 0030	POLE 60 3,5M - 1 BASE

Notes: