







LASS-OH! POWERBOX

DEEL
PARTIE
TEIL
PART
PARTE
PARTE

A














 **IP20**

Beschermd tegen vaste voorwerpen die groter zijn dan 12 mm
Protégé contre les objets solides de plus de 12 mm
Geschützt gegen Festkörper größer als 12 mm
Protected against solid objects greater than 12 mm
Protegido contra objetos sólidos superiores a 12 mm
Protetto contro oggetti solidi più grandi di 12 mm



Voorzien van aardingsaansluiting
Avec mise à la terre
Ausgerüstet mit Erdungsanschluss
Provided with grounding
Con la toma de tierra
Con presa a terra







300mA-1050mA					250mA-1000mA				
SEC	1	2	3	4	SEC	1	2	3	4
300 mA	-	-	-	-	250 mA	-	-	-	-
350 mA	-	-	-	ON	300 mA	-	-	-	ON
400 mA	-	-	ON	-	350 mA	-	-	ON	-
450 mA	-	-	ON	ON	400 mA	-	-	ON	ON
500 mA	-	ON	-	-	450 mA	-	ON	-	-
550 mA	-	ON	-	ON	500 mA	-	ON	-	ON
600 mA	-	ON	ON	-	550 mA	-	ON	ON	-
650 mA	-	ON	ON	ON	600 mA	-	ON	ON	ON
700 mA	ON	-	-	-	650 mA	ON	-	-	-
750 mA	ON	-	-	ON	700 mA	ON	-	-	ON
800 mA	ON	-	ON	-	750 mA	ON	-	ON	-
850 mA	ON	-	ON	ON	800 mA	ON	-	ON	ON
900 mA	ON	ON	-	-	850 mA	ON	ON	-	-
950 mA	ON	ON	-	ON	900 mA	ON	ON	-	ON
1000 mA	ON	ON	ON	-	950 mA	ON	ON	ON	-
1050 mA	ON	ON	ON	ON	1000 mA	ON	ON	ON	ON

OR

12



13



De verlichtingsbron van dit verlichtingstoestel zal enkel door de fabrikant of door de fabrikant aangestelde installateur vervangen worden.

La source lumière de cet appareil ne sera remplacée que par l'entreprise ou par un agent reconnu.

Das enthaltene Leuchtmittel sollte nur durch entsprechendes Fachpersonal ersetzt werden.

The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent.

La fuente de iluminación que tiene esta luminaria sólo puede remplazarse por el fabricante o por un instalador autorizado.

La sorgente luminosa incorporata in questo apparecchio può essere sostituita solo dal produttore, da un suo centro assistenza oppure da una persona in possesso della necessaria abilitazione.